

NK390.65

Quick guide

Ignition key code for programming the ECU

1. Turn the ignition key ON and OFF 3 times.
2. Turn the throttle to full throttle and STOP! Switch the ignition key ON and OFF again 3 times.
3. Wait until the engine control flashes 1x. Then release the throttle and switch off the ignition.
4. Start the vehicle and leave it stationary for at least 15 minutes.
5. Turn the ignition key ON and OFF 5 times, wait 20 seconds.
6. Done!

